SAMSUNG

ENGLISH

OWNER'S MANUAL

REFRIGERATOR

Before operating the unit, please read this manual throughly,
and retain for future reference.

※ If you took out of the power supply outlet, you should plug in again after five minutes.

DA99-00477K REV(0.0)

FEATURE

Uniform supply of cold in refrigerating room!

- Food can be refrigerated more freshly and evenly by supplying cold even to the corners by means of rotating wings to distribute cold, which are installed to the cold outlet of the refrigerating room.(Rotating cooling system).

Uniform supply of cold in the freezing room!

- Foods can be freezed more evenly by the air shower function to jet cold evenly in the freezing room.

Being fresh by Bio deodorizer!

- Bio deodorizer that remove every kinds of foods smell in refrigerator maintains the origin flavor of foods newly.

Rapid opening and closing by rail system!

- Vegetables and fruits can be rapidly accessible to prevent loss of cold by employing a rail style design in high-humidity vegetable room and high-humidity special room which operates smoothly only by pulling and pushing a handle effortlessly.

Even slightly opened door is closed automatically by itself!

- In case of slight opening of refrigerator door, it will be closed automatically by employing energy-saving, automatic closing function.

X-Flow cooling system is a new rotating cooling system that refrigerates the inside of refrigerator quickly and uniformly by rotating wings tramsmitting cold in all the corners.

Warning

- Before operating the appliance, please read this manual thoroughly and retain it for your reference.
- Because these following operating instructions cover various models, the characteristics of your refrigerator may differ slightly from those described in this manual.
- The appliance is not intended for use by children or infirm persons without adult supervision.
- Children should be supervised to ensure that they do not play with the appliance.
- The appliance must be positioned so that the plug is accessible after installation.

CONTENTS

FEATURE — 1
WARNING FOR SAFETY — 2
CAUTION FOR SAFETY — 4
PREPARATIONS PRIOR TO USE — 6
HOW TO STORE FOODS CORRECTLY — 7
INSTALLATION METHOD — 8
HOW TO USE FREEZING ROOM — 9
HOW TO USE REFRIGERATING ROOM — 11
HOW TO DISASSEMBLE ACCESSORIES — 14
CLEANING METHOD — 16
PROCEDURE OF INSTALLATION — 18
CAUTIONS WHEN USING — 19
CHECKS PRIOR TO SERVICE REQUEST — 20
ANSWER TO THE QUESTION — 22

WARNING FOR SAFETY

This is to prevent users or other persons from being wounded or injured, by using the present product properly. Be sure to observe these contents for safety. (After reading these contents, please keep in such a safe place as to look up)

Contents of Caution/Warning

Warning	Represents the contents that death or heavy injury of a person is foreseen.
Caution	Represents the contents that injury of a person or damage of material is foreseen.

Contents of indication

	Represents the contents of prohibition.
	Represents the prohibition of disassembly.
	Represents the prohibition of contact.
	Represents what has to be observed.
	Represents that a power plug has to be separated from the plug socket.
	Represents earth for prevention of electric shock.

Warning

Do not insert the power plugs for many products at the same time.

- May cause abnormal generation of heat or fire.



Set the power plug free from the back side of the refrigerator.

- Damaged power plug may cause fire due to overheating.



Do not directly spray water inside or outside of the refrigerator

- May cause fire or electric shock.



Do not spray inflammable gas near the refrigerator.

- May cause explosion or fire.



Do not bend the power cord with excessive force or do not have the power cord pressed by heavy article.

- May cause fire or electric shock.(If the power cord is damaged, avoid a hazard by replacing it through the manufacturer or its service agent or a similarly qualified person.)



Do not store a volatile and inflammable substance in the refrigerator.

- Storage of benzene, thinner, alcohol, ether, LP gas, etc., may cause explosion.

Warning

Do not put a container filled with water on the product.

- If water poured, it cause bad insulation of the electric parts which may lead to fire or electric shock.



Do not install the refrigerator in the wet place or the place which water splashes.

- Deterioration of insulation of electric parts may cause electric shock or fire.



Do not insert the power plug with the wet hand.

- May cause electric shock.

Do not disassemble, repair or alter.

- It may cause fire or abnormal operation which leads to injury.



Pull the power plug out for exchanging the interior lamp of the refrigerator.

- It may cause electric shock.



Be sure to earth.

- If earthing is not done, it will cause breakdown and electric shock. (Please refer to page 6).



If and when gas leaks, immediately ventilate without touching the refrigerator and the plug.

- Explosion of gas may cause fire and a burn.



Dispose refrigerator after door or door's packing is removed, if disposition is required.

- It is dangerous for child to enter the refrigerator for play-in with door closed.



CAUTION FOR SAFETY

Caution

Do not store too much foodstuffs therein.
- Opening of the door may cause pouring over which may inflict a wound.



Do not store narrow and lengthy bottles or foods in a small multi-purpose room.
- It may hurt you when refrigerator door is opened and closed resulting in falling stuff down.

If the hole of the power plug socket is loose, do not insert the power plug.
- It may cause electric shock and fire.



Do not put bottles or kinds of glass in the freezing room.
- Freezing of the contents may inflict a wound.



Do not store articles on the product.
- Opening or closing of the door may cause throwing down which may inflict a wound.

Do not pluck out the power cord by pulling the portion of it.
- Damage of the cord portion may cause fire and electric shock.



Do not let a child be hung down from the door.
- Injury may occurs, when the product falls down or a finger is jammed in the door.



Do not store pharmaceutical products, scientific materials, etc., in the refrigerator.
- The products which temperature control shall be strict shall not be stored in the refrigerator.

Caution

Do not touch the container and the food stuffs of the freezing room with the wet hand.

- It may cause frostbite.

Do not enter the hand into the bottom surface of the product.

- Sharp edge may inflict a wound.



Please wipe out foreign materials of the metal option of the power plug cleanly.

- Use of it as it is may cause fire.



If you want to insert the power plug again, please insert it five minutes after pulling out of the plug socket.

- Abnormal operation of freezing device may cause breakdown of it.



Move it by catching the upper handle of rear side and the lower handle of front side.

- Slippery is caused to hurt, when other part is grasped.



Use handle when opening and closing the refrigerator door.

- In case of using other parts than handle, it may hurt you with your finger jammed.



If the refrigerator is not to be used for a long time, pull out the power plug.

- Due to deterioration of insulation, may cause fire.



When abnormal sound, smell or smoke is noticed, pull a power plug off immediately, then call service center.



PREPARATIONS PRIOR TO USE

1 The refrigerator should be installed on flat floor leaving adequate space.

- Unusual noises or poor cooling may arise when the unit is not levelled.



2 Clean up the refrigerator

- Wipe out the inner and outer parts of the unit with a dish cloth which was squeezed dry.



3 Insert a power plug into the exclusive receptacle.

- Earth connection should be done.
- It is recommended to connect power one hour after installation.



4 Put foods into the refrigerator.

- It is recommended to put foods into the unit after plugging-in 2 or 3 hours before stuffing to allow cooling in the unit.



Grounding method

- Grounding should be done to prevent short circuit or electric shock resulting from the electricity leaking from the refrigerator.
- Do not ground with gas pipe, telephone line or lightning arrester without fail because of being very dangerous when lightning strikes.

In case of the exclusive electric outlet with a grounding terminal.

- In case of electric outlet with a grounding terminal, it does not require a separate grounding connection.



In case of the electric outlet without a grounding terminal.

- Connect the "grounding wire" to the copper plate, and bury it in the wet ground 25cm deeper.



HOW TO STORE FOODS CORRECTLY

Store watery foods in front of shelf of refrigerating room.



Cool the hot foods, then store them.

- Electric charges will reduce and cooling will be much effective provided that hot foods are cooled.



Do not store the foods which are perishable at low temperature.

- i.e.: Banana, Pineapple, Tomato etc.



Put foods at proper space.

- In case of cooling outlet plugged, storing effect of food decreases because of poor circulation of cold.



It is recommeded to store in a vessel with cover or after wrapping-up with a vinyl sheet.



INSTALLATION METHOD

Allowing a 5cm space on the right, left and back sides when installing the unit, makes you have an advantage in saving power consumption.



LEVEL THE REFRIGERATOR

When you install the front of the unit on a little higher level, its door can be easily opened and closed.

1 **When the door is sagged to the left, downward.**
Turn the left adjusting leg to the arrow direction and level the unit.



2 **When the door is sagged to the right, downward.**
Turn the right adjusting leg to the arrow direction and level the unit.



HOW TO USE FREEZING ROOM


ICE BOX
Temperature controller in freezing room
Indoor light in freezing room
Drying room
Suction inlet of cold
Airshower: Function of airshower- foods can be frozen more evenly by function of jetting cold uniformly in freezing room. (Option)



Electronic model

HOW TO PRODUCE ICE

1 Pour water into ice box at a level of water (Arrow).



2 Put the ice box in the air shower shelf of the freezing room.



HOW TO CONTROL TEMPERATURE IN FREEZING ROOM

1. Mechanic model

COLDER :

When storing much quantities of foods to be frozen, or producing ice quickly .

- Adjust the temperature controller in the freezing room to the "COLDER" position.

COLDER to COLD :

When using in average.

- Adjust the temperature controller in the freezing room between "COLDER" and "COLD" position .

COLD :

When storing few quantity of foods to be frozen.

- Adjust the temperature controller in the freezing room to the "COLD" position.

2. Electronic model

Push the "**CONTROL TEMP**." button.

- You can choose the temperature (Ultra, High, Middle, Low) depends on the amount of food.
- If you push the button, you can see lighting moved in the following order. (ex ; Middle → High → Ultra → Low)
- It means "ULTRA" that all lamps are on.(Store large quantities of food)

Push the "**QUICK FREEZE**" button.

- You can push this button, when you want to make the ice or cool the food quickly.
- If you push this button, the lamp will be on and it will work.
- If you want to stop the function, push the button one more.

Push the "**DOOR ALARM**" button.

- You can check the airtight of door with the alarm.
- If the door of refrigerator is left opened over the angle of 5°, the alarm will operate for 10 second every 2 minute repeatedly.
- As soon as you plug in a refrigerator, this function will operate. If you don't use this function, push this button and then you will see the lamp off.

REFERENCE

- Put the foods to be stored for a long time in the freezing room, such as ice cream, fish, and meat, etc.
- It is recommended to store the dried foods in the dry room, such as dried fish, pepper powder which dislike humidity.

In the following case, smell may arise from ice.

- Storing the uncovered meat or fish.
- Storing foods packed with the smelling package such as vinyl.

HOW TO USE REFRIGERATING ROOM



REFERENCE Frequent opening of refrigerator door may produce dew inside of the unit.

HOW TO CONTROL TEMPERATURE IN REFRIGERATING ROOM

COLDER :
When storing much quantities of foods to be refrigerated or not being cold enough.

- Adjust the temperature controller in refrigerating room to the "COLDER" position.

COLDER to COLD :
When using in average.

- Adjust the temperature controller in refrigerating room between "COLDER" and "COLD" position.

COLD :
When the food refrigerated are frozen, or the foods are in a small quantity.

- Adjust the temperature controller in refrigerating room to the "COLD" position.

CAUTION In case surrounding temperature is less than 5°C, the temperature should be lower than average to prevent the stored foods against getting frozen.

HOW TO STORE FOODS FOR REFRIGERATION

1 High-humidity special room

- Store the foods which are just ready for cooking such as meat, fish and raw fish, and are slightly frozen.



2 Shelf of refrigerating room

- Store the side dishes contained in storage vessels and other storage foods at suitable intervals.



3 Egg tray

- Store eggs.
- Egg tray may be used as a multi-purpose room only by removing the egg tray.



4 Guard variety

- Store the small-packed storage foods like butter, milk, yogurt etc. and beverages.



5 Jumbo Guard bottle

- Store beer, 1L milk, juice in the lower part, and 1.5L or 2.0L vessel or water bottle in the upper part.

Upper part

Lower part

6 High-humidity vegetable room

- The rail style high-humidity vegetable box is a cased indirect cooling system to reach the foods with cold. So that origin moisture is maintained for a long time.



HOW TO DISASSEMBLE ACCESSORIES



1 Shelf of High humidity special room

- Lift upward the special room cover, and push the right side(No.①) inward to remove, and remove the left side(No.②) toward arrow, then pull it.
- While removing the special room shelf toward arrow, lift it upward at the hanging point for removal.

Procedure of disassemble



- Lift slightly the front part of special room shelf, and insert roller between rails, then push it.
- Insert the left part (No.①) of special room as direction of arrow, and pull the right hanging part(No.②) inward as direction of arrow untilinserting.

Procedure of assemble



2 Shelf of freezing room

- First, remove ice box, and lift the front part of the shelf and pull out to remove it.



3 Bio deodorizing device

- Press and remove downward the end part of hanging jaw in front of Bio deodorizing device located on the top of refrigerating room.



4 Shelf of refrigerating room

- Hold the front part of the shelf in refrigerating room, and pull it forward until removing.



5 Beverage room

- Lift it upward, then remove it.



6 Cover and box of vegetable room

- Lift upward and remove the vegetable box, and pull the vegetable box forward to the middle, then remove it raising it upward.



CLEANING METHOD



1 Ice cube maker

- Clean up the ice cube maker with water after pulling it out.

2 Suction inlet of cooling air in freezing room.

- Wipe the suction inlet with a dried cloth according to vertical texture not to cover with alien substance.



3 Shelf of refrigerting room.

- Remove the shelf of refrigerating room, then clean it up using water and detergent.



4 Bio Deodorizer

- If the refrigerating room smells bad, please seperate the Bio deodorizer, soak the catalyst in pure water and dry it to sunlight before use.



5 Guard bottle

- Wash to guard bottle with water after pulling it out.



6 Rubber packing

- Clean up the rubber packing with a dish cloth which is wet with detergent, and between grooves with a wooden chopstick wrapped up by a cut of cloth.



7 High-humidity ware vegetable drawer

- Wipe out the vegetable drawer using a wet cloth after pulling it out.



⚠ Warning

- Disconnect the power plug and open the door for dry when cleaning or out of operating for a long time.
- Do not spray water for clean-up, and do not use benzene or thinner, either.

PROCEDURE OF INSTALLATION

CAUTIONS WHEN INSTALLING

1 Do not put the inflammables into the unit.

- Flammable sprays may cause fire.
- Plugging-out is dangerous while leaking gas.



2 Avoid heat sources or moisture.

- Rusting or decolorating may happen.



3 Do not store goods on the top or rear.

- Poor circulation of air may affect cooling function because heat does not escape.
- Do not put things on the top of the refrigerator because they are liable to dropping down.



4 Install the unit in the place where surrounding temperature is low.

- Cooling efficiency gets better.
- The unit should be away from the direct sunlight.



REPLACING METHOD OF INDOOR LIGHT

CAUTION

- Pluck out the power cord, first.

1 Indoor light of freezing room.

- Insert ⊖driver into the rear groove of light cover, and pull it forward, then remove it downward. After replacing the light, insert thefront part first, and then the rear part by fixing the groove.



2 Indoor light of refrigerating room.

- Remove the shelf of special room. Press the top of the light cover with driver, and pull it forward lowering a little, then replace the indoor light after removing the cover.



CAUTIONS WHEN USING

1 Do not put bottles or kinds of glass in the freezing room.

• Freezing of the contents may inflict a wound.



2 Do not bend the power cord with excessive force or do not have the power cord pressed by heavy article.



3 Do not let a child be hung down from the door.



4 Cool the hot foods, then store them.

• Electric charges will reduce and cooling be much effective provided that hot foods are coolded.



5 Store watery foods in front of shelf of refrigerating room.



6 Foods should be stored in a vessel with cover or after wrapping-up with a vinyl sheet.



CHECKS PRIOR TO SERVICE REQUEST

SYMPTOMS	CHECKS
The unit is not operating at all, or refrigerating weakly. 	• Check if power plug is connected well. • Is the temperature control in front operating part "COLD"? • Does sun shine on the unit, or are there heat sources near by? • Is there the back of the unit too near to the wall?
The foods in the refrigerator are frozen 	• Is the temperature control in front operating part "COLDER"? • Is the surrounding temperature too low? • Did you put the watery foods into the cold inside?
There are unusual noises 	• Check if the unit is installed on a firm or weak floor. • Is there the back of the unit too near to the wall? • Is any foreign material dropped behind or under the unit? • Isn't the noise from the compressor in the unit? • Sound of "ticking" may be heard from the unit's inside, but it is not out of order. This sound comes when various accessories are contracted or expanded by cooling function.
The front corners and sides of the unit are getting hot and dewdrops form thereon. 	• Heat-proof pipes are installed in the front corners of the unit to prevent forming dew. When the surrounding temperature rises, there might be not feeling in some cases. However, this is not abnormal. • In high humid weather, dewdrops might form on the outer surface of the unit with the result that the moisture in the air contacts with the cool surface of the unit.

SYMPTOMS	CHECKS
There are babbling of water in the unit 	• This is a babbling of refrigerant which refrigerates the inside of the unit.
There is odoring inside of the unit 	• You did not seal the foods which had an odor. • When it smells bad, please clean the bio deodorizer. • Store the odoring foods after they are covered, and clean up the cold inlet.
There is a layer of frost in the unit's walls. 	• Isn't the air outlet of the unit plugged? • Keep the foods spaced to be ventilated well. • Isn't the door closed fully?
Dew forms on the inside wall of the unit and around ware vegetable. 	• When the watery foods are stored without cover in the high humid surrounding, or with the door opened for a long time. • Store the foods with cover or sealed.

ANSWER TO THE QUESTION

WHAT IS BIO DEODORIZER?



1 The Bio deodorizer is installed to the suction inlet of cold in the refrigerator so that air circulates automatically without any assist and removes food smell.



2 This deodorizer is designed to absorb and dissolve completely, and its ability of depolarization is excellent.



REFERENCE

- The Bio deodorizer's life span is semi-permanent.
- The function of the Bio deodorizer is not harmful to the storage foods or person at all, but is used only to remove the smell from the storage foods in the refrigerator.

CAUTION

- For the storage of the food which have a strong smell, store it using lap or putting in a covered container, because it may have a decreased effect of depolarization resulting from soaking smell into the refrigerator wall or other foods.

SAMSUNG
ELECTRONICS

ELECTRONICS

الجواب عن الأسئلة

ما هو مزيل بايو للروائح الكريهة



مزيل بايو للروائح الكريهة

١

يتم تركيب مزيل الروائح الكريهة في مدخل امتصاص الهواء البارد في حجيرة التبريد ، لذلك يدور الهواء اوتوماتيكيا بدون اية رائحة وتتم ازالة رائحة الطعام.



٢

مزيل الروائح الكريهة هذا مصمم لامتصاص الروائح الكريهة وازالتها تماما. وقدرة المزيل على ازالة الاستقطاب ممتازة. خاصة هذا يزيل الروائح القوية المنبعثة من الاطعمة الكورية التي يسهل امتصاصها .

ملاحظات

- عمر مزيل الروائح الكريهه يبقى شبه دائم.
- وظيفة مزيل الروائح الكريهة لا تؤثر تأثيرا ضارا على الأطعمة المحفوظة أو جسم الإنسان ابدا بل يزيل الروائح الكريهة من الاطعمة المحفوظة داخل حجيرة التبريد.

تحذير

- لحفظ الأطعمة ذات الروائح القوية ، احفظها بعد تغطيتها أ وضعها في وعاء بغطاء، لان الاطعمة ذات الروائح القوية تخفض كفاءة ازالة الاستقطاب بسبب امتصاصها الى جدران الثلاجة أو غيرها من الاطعمة في الثلاجة.

الخلل	افحص
يصدر صوت جريان الماء الثلاجة 	• صوت جريان الماء للمبرد يصدر عند عملية التبريد داخل الجهاز.
الروائح داخل الثلاجة 	• لم تغط الأطعمة ذات رائحة باي غطاء. • عند نشوء الروائح الكريهة ، يرجى تنظيف مزيل الروائح الكريهة. • احفض الاطعمة ذات رائحة بعد تغطيتها ونظّف مدخل الهواء البارد.
وجود الصقيع على جدران الثلاجة 	• أ ليس مخرج الهواء في حجيرة التجميد مسدودا ؟ • اترك مسافة بين الأطعمة لدوران الهواء الجيد. • أليس الباب مغلقا تماما ؟
وجود نداوة في جدران الثلاجة 	• عند حفظ الاطعمة الرقيقة بدون غطاء في حالة وحول درج الخضراوات وجود الرطوبة العالية حولها أو فتح الباب لمدة طويلة . • احفظ الاطعمة بغطاء أو لف مختوم.

افحص النقاط أولا قبل طلب الخدمات

الخلل	افحص
لا تعمل الثلاجة أو تعمل التبريد السيئ 	• افحص التوصيل الى الطاقة الكهربائية • هل ضبطت درجة الحرارة على اللوحة الأمامية الى وضعية "COLD (البارد)" ؟ • هل تعرض الثلاجة لاشعة الشمس المباشرة أو توجد مصادر الحرارة قريبا من الثلاجة؟ • هل اللوحة الخلفية للثلاجة قريبة من الجدار أكثر من اللازم ؟
تتجمد الأطعمة في حجيرة التبريد 	• هل ضبطت درجة الحرارة على اللوحة الأمامية على وضعية "COLDER(الأبرد)" ؟ • هل درجة الحرارة حول الثلاجة مرتفعة جدا ؟ • أ لا تضع الأطعمة الرقيقة داخل حجيرة التبريد بعمق ؟
يحدث الضجيج غير العادي 	• افحص ان الأرض غير مستوية أو غير ثابتة. • هل اللوحة الخلفية للثلاجة قريبة من الجدار أكثر من اللازم ؟ • هل توجد الأشياء الغريبة خلف الثلاجة أو تحت الثلاجة ؟ • هل ينشأ الضجيج من الضاغط داخل الثلاجة ؟ • قد تسمع صوت "تيك" من داخل الثلاجة ولكنه لا يعني حدث اي عطل. هذا الصوت يصدر عند تلامس الملحقات المختلفة أو تمديدها عند وظيفة التبريد.
درجة الحرارة حول الثلاجة مرتفعة جدا وتحدث نداوة على الثلاجة 	• تم تركيب انابيب مضادة للحرارة في اللوحة الأمامية للثلاجة لمنع تكوين نداوة. ترتفع درجة الحرارة حول الثلاجة احيانا. ولكن هذا امر طبيعي. • في الجو عالي الرطوبة، قد تحدث النداوة على اسطح الجهاز نتيجة ملامسة الهواء ذي الرطوبة بالاسطح الباردة للثلاجة.

تحذيرات عند التشغيل

١ لا تحفظ الزجاجات أو نوعا من الزجاج في حجيرة التجميد.

• تجميد المحتويات قد يؤدي الى إحداث ضرر.

٢ لا تقم بلي سلك التيار الكهربائي بالقوة أو لا تضغط على سلك التيار الكهربائي بالشيء الثقيل.



٣ لا تترك ولدا يعلق بباب الثلاجة.



٤ برّد الاطعمة الساخنة ثم احفظها في الثلاجة.

• هذا يخفض مبلغ فاتورة الكهرباء وترتفع كفاءة التبريد عند حفظ الاطعمة بعد تبريدها.



٥ احفظ الأطعمة الرقيقة في أمام الرف في حجيرة التبريد.



٦ لا بد حفظ الاطعمة في وعاء ذي غطاء أو بعد لفها بالفينيل الصحفي.

تحذيرات عند التركيب

١ لا تضع أشياء قابلة للاشعال في الثلاجة.

- رش الأشياء القابلة للاشعال قد يؤدي الى حدث احتراق.
- من الأمر الخطير اخراج القابس من مخرج التيار في حالة تسرب الغاز.

٢ تجنب مصادر الحرارة أو الرطوبة.

- هذه قد تؤدي الى تلويث الثلاجة بالغبار أو إحداث تغيير اللون.



٣ لا تحفظ الأشياء على أعلى الثلاجة أو خلفها.

- دوران الهواء الضعيف قد يؤثر على وظيفة التبريد بسبب عدم ازالة الحرارة.
- لا تضع الأشياء على أعلى الثلاجة لانها تسقط الى الأسفل بسهولة.

٤ ركب الثلاجة في المكان الذي تكون درجة الحرارة حوله منخفظة.

- هذا يضمن كفاءة التبريد الأفضل.
- تجنب من أشعة الشمس المباشرة.

كيفية تبديل المصباح الداخلي

تحذير : افصل قابس الثلاجة من مخرج التيار الجداري أولا.

١ المصباح الداخلي في حجيرة التجميد

- ادخل مفك برغى الى الأخدود الخلفي من غطاء المصباح واسحبه الى الأمام ثم اخرجه الى الأسفل.

بعد تبديل المصباح، ادخل الجزء الأمامي من غطاء المصباح اولا ثم الجزء الخلفي منه بتثبيت الأخدود.



٢ المصباح الداخلي في حجيرة التبريد

- اخرج رف الحجيرة الخاصة.

اضغط على الجزء العلوي من غطاء المصباح بمفك برغى واسحبه الى الأمام بضغطه الى الأسفل قليلا، ثم اخرج الغطاء واستبدل المصباح الداخلي.



٣ رف حجيرة التبريد

• ازل رف حجيرة التبريد، ثم نظّفه بالماء ومسحوق الغسيل.



٤ مزيل الروائح الكريهة

• اذا انبعثت الروائح الكريهة من حجيرة التبريد، يرجى فصل مزيل بايو للروائح الكريهة، انقع الحفاز في الماء الصافي وجففه تحت اشعة الشمس قبل استخدامه.



٥ حامل الزجاجات

• اغسل حامل الزجاجات بالماء بعد إخراجه.

٦ الحشية المطاطية

• نظّف الحشية المطاطية بقطعة من القماش المبلل الخاص لغسيل الطبق مع مسحوق الغسيل ، ونظّف الجزء بين الاخدودين بعود خشبي ملفوف بقطعة من القماش.



٦ الحجيرة الخاصة للاطعمة طازجة مع الرطوبة العالية

• امسح درج الخضراوات بقطعة من القماش المبلل بعد سحبه الى الخارج.



⚠ تنبيهات

• افصل قابس التيار الكهربائي من مخرج التيار الجداري وافتح الباب للتجفيف عند انتهاء عملية التنظيف لمدة طويلة.

• لا ترش الماء للتنظيف ولا تستخدم البنزين أو مرقق القوام و الأثير.

كيفية التنظيف



١ صانع المكعبات الثلجية

• نظّف صانع المكعبات الثلجية بالماء بعد سحبه الى الخارج.

٢ مدخل امتصاص الهواء البارد في حجيرة التجميد.

• امسح مدخل الامتصاص بقطعة من القماش الجاف حسب الحالة العمودية لكي لا تغطي المدخل بشيء .



٢ اداة ازالة الروائح الكريهة

• اضغط على نقطة التعليق واسحب اداة ازالة الروائح الكريهة الموجودة على سقف حجيرة التبريد.



٣ اداة ازالة الروائح الكريهة

• اضغط على نقطة التعليق واسحب اداة ازالة الروائح الكريهة الموجودة على سقف حجيرة التبريد.



٤ رف حجيرة التبريد

• امسك الجزء الأمامي من الرف في حجيرة التبريد واسحبه الى الأمام حتي تخرجه.



٥ حامل المشروبات

• ارفعه الى الأعلى ثم اخرجه.



٦ غطاء حجيرة الخضراوات وصندوقها

• ارفع غطاء حجيرة الخضراوات واخرجه واسحب صندوق الخضراوات الى الأمام بامساك وسطه ثم ارفعه الى الأعلى واخرجه.



كيفية فصل الملحقا



١ حجيرة التبريد الخاصة لحفظ الاطعمة طازجة مع الرطوبة العالية

- ارفع غطاء الحجيرة الخاصة الى الأرعلى واسحب جانبه اليمين (رقم ١) الى الداخل لإخراجه، واسحب جانبه اليسار (رقم ٢) ثم اخرج الغطاء.
- أثناء اخراج رف الحجيرة الخاصة باتجاه السهم، ارفعه الى الأعلى في نقطة التعليق لاخراجه.
- ارفع الجزء الأمامي من رف الحجيرة الخاصة بقليل وادخل الملف الى السكة ثم ادفع الرف الى الداخل.
- ادخل الجزء اليسار (رقم ١) من رف الحجيرة الخاصة باتجاه السهم، وادفع جزء التعليق اليمين(رقم ٢) الى الداخل باتجاه السهم حتى تدخله اليه.

إجراءات الفصل



إجراءات التجميع



كيفية حفظ الاطعمة في حجيرة التبريد

١ حجيرة التبريد الخاص لحفظ الأطعمة طازجة

• احفظ الأطعمة الجاهزة للطبخ فقط مثل اللحم ، السمك، والسمك غير المطبوخ ، والتي يتم تجميدها قليلا.



٢ رف في حجيرة التبريد

• احفظ الأطعمة التابعة في وعاء الحفظ أو احفظ الاطعمة على مسافة مناسبة.



٣ حامل البيضات

• احفظ البيضات في الحامل.
• قد يستخدم حامل البيضات لحجيرة متعددة الأغراض فقط بإزالة صينية البيضات.



٤ حامل الاشياء المختلفة

• احفظ الأطعمة المعلبة الصغيرة مثل الزبدة ، والحليب ، واللبنة (يوجروت) أو المشروبات.



٥ حامل الزجاجات الكبير

• أخفض البيرة ، والحليب بـ١ لتر ، والعصير في أسفل الحامل واخفض وعاء بـ ١.٥ لتر أو ٢,٠ لتر أو زجاجات من الماء في أعلى الحامل.

في أسفل الحامل

في أعلى الحامل

٦ حجيرة الخضراوات مع الرطوبة العالية

• حجيرة الخضراوات مع الرطوبة العالية من نوع السكة تتخذ طريقة التبريد غير المباشر بواسطة الدارة من أجل منع الهواء البارد من وصوله الى الأطعمة مباشرة مما يؤدي الى حفظ الأطعمة في حالة انها تحتفظ بالرطوبة الأصلية لمدة طويلة جدا.



كيفية ضبط درجة الحرارة في حجيرة التبريد

الأبرد:

عند حفظ كمية أكثر من الأطعمة في حجيرة التبريد ، أو عدم التبريد الكافي.

• اضبط ضابط درجة الحرارة في حجيرة التبريد على وضع "COLDER (الأبرد)".

الأبرد الى البارد

عند تشغيل الثلاجة على معدل درجة الحرارة.

• اضبط ضابط درجة الحرارة في حجيرة التبريد على وضع بين "COLDER (الأبرد)" و "COLD (البارد)".

البارد

عند تجميد الأطعمة في حجيرة التبريد، أو حفظ كمية أقل من الأطعمة.

• اضبط ضابط درجة الحرارة في حجيرة التبريد على وضع "COLD (البارد)".

ملاحظة

في حالة درجة الحرارة حول الثلاجة منخفضة أقل من ٥° م ، لا بد ضبط درجة الحرارة أقل من معدل درجة الحرارة لمنع الأطعمة المحفوظة في حالة عدم تجميدها.

كيفية استخدام حجيرة التبريد



تركيب فتح باب الثلاجة قد يؤدي الى إحداث نداوة داخل جهاز الثلاجة.

ملاحظة

كيفية ضبط درجة الحرارة في حجيرة التجميد

الأبرد :

عند حفظ كمية أكثر من الأطعمة في حجيرة التجميد ، أو صنع المكعبات الثلجية بسرعة.

• اضبط ضابط درجة الحرارة في حجيرة التجميد على وضع "COLDER (الأبرد)".

الأبرد الى البارد

عند تشغيل الثلاجة على معدل درجة الحرارة.

• اضبط ضابط درجة الحرارة في حجيرة التجميد على وضع بين "COLDER (الأبرد)" و "COLD (البارد)".

البارد

عند حفظ كمية أقل من الأطعمة في حجيرة التجميد.

• اضبط ضابط درجة الحرارة في حجيرة التجميد على وضع "COLD (البارد)".

---

٣. الموديل الإلكتروني

اضغط على زر «**ضبط درجة الحرارة**» .

- يمكنك اختيار درجة الحرارة (عالية جدا ، عالية ، متوسطة، منخفضة) حسب كمية الأطعمة.
- إذا ضغطت على الزر ، يمكنك مشاهدة المؤشر المتحرك بالترتيب التالي.
  (مثلا : متوسطة ← عالية ← عالية جدا ← منخفضة)
- تعني كلمة " عالية جدا" أن جميع اللمبات تعمل. (لحفظ كمية كبيرة من الأطعمة).

اضغط على زر «**التجميد السريع**» .

- يمكنك الضغط على هذا الزر ، عندما تريد صنع الثلج أو تبريد الطعام بسرعة.
- إذا ضغطت على هذا الزر ، يضاء المؤشر ويعمل.
- إذا أردت إيقاف الوظيفة، اضغط على الزر مرة أخرى.

اضغط على زر «**إنذار فتح الباب**».

- يمكنك التأكد من إغلاق الباب بإحكام بواسطة الإنذار .
- إذا تركت باب الثلاجة مفتوحا بدرجة أكثر من ٥°، يعمل الإنذار لمدة ١٠ ثوان كل دقيقتين تكرارا.
- حالما وصلت قابس الجهاز الى مخرج التيار ، تعمل هذه الوظيفة. إذا لم تستخدم هذه الوظيفة ، اضغط على هذا الزر وعندها تشاهد إيقاف المؤشر.

ملاحظات

- احفظ الأطعمة في حجيرة التجميد لمدة طويلة مثل ايسكريم ، سمك ، لحم الخ
- من الأفضل ان تحفظ الأطعمة المجففة في حجيرة التجفيف مثل السمك المجفف ، مسحوق فلفل أحمر يكره الرطوبة.

في الحالة التالية، قد تحدث الروائح من الثلج.

- حفظ اللحم أو السمك في حالة عدم تغطيته.
- حفظ الأطعمة المجففة مثل الحبار ، الأنشوفة ، اللافر ، سمك آخر مجفف في حالة عدم تغطيتها.
- حفظ الأطعمة المعلبة بتغليف ذي رائحة مثل فينيل.

كيفية استخدام حجيرة التجميد


صندوق الثلج
ضابط درجة الحرارة في حجيرة التجميد
الضوء الداخلي في حجيرة التجميد
حجيرة الأشياء المجففة
الشلال الهوائي : وظيفة الشلال الهوائي – يمكن تجميد الأطعمة بشكل متساو أكثر بوظيفة التبريد السريع في حجيرة التجميد. (اختياري)
مدخل الامتصاص للهواء البارد



الموديل الإلكتروني

كيفية صنع المكعبات الثلجية

١ صبّ الماء على صندوق المكعبات الثلجية حتي يصل الماء الى مستوى الماء (السهم).



٢ ضع صندوق المكعبات الثلجية في رف دش الهواء في حجيرة التجميد.



كيفية التركيب

اترك مسافة بـ ٥ سم من الجانبين اليمين واليسار واللوحة الخلفية الى الجدران عند تركيب الثلاجة وهذا يجعلك تتمتع بتوفير الطاقة الكهربائية.



استواء الثلاجة

عند تركيب جهاز الثلاجة وأمامه مرتفع بقليل ، يمكنك فتح الباب وإغلاقه بسهولة.

١ عند ميل الباب الى اليسار الأسفل.

ادر الرجل اليسار القابل لتعديل الارتفاع باتجاه السهم واضبط استواء الجهاز.



٢ عند ميل الباب الى اليمين الأسفل.

ادر الرجل اليمين القابل لتعديل الارتفاع باتجاه السهم واضبط استواء الجهاز.

كيفية حفظ الاطعمة الصحيح

احفظ الاطعمة الرقيقة على أمام الرف في حجيرة التبريد.



احفظ الاطعمة الساخنة بعد ان تبرّدها.

• هذا يخفض مقدارا مستهلكا من الطاقة ويرفع كفاءة التبريد أكثر عند تبريد الأطعمة الساخنة.



لا تحفظ الاطعمة التي تصبح فاسدة بسهولة في درجة الحرارة المنخفضة.

• مثلا : موز ، اناناس ، طماطم الخ



ضع الأطعمة على مسافة مناسبة.

• اذا كان مخرج الهواء البارد مسدودا، تنخفض كفاءة الحفظ الباردة بسبب سوء دوران الهواء البارد.



من الأفضل أن تحفظ الاطعمة في وعاء مع غطاء أو بعد تغطيتها بفينيل صفحي.

الإجراءات الاستعدادية للتشغيل

١
لا بد من تركيب جهاز الثلاجة في أرض مستوية وثابتة ومكان كافي المساحة.

• قد يحدث الضجيج غير العادي أو التبريد الضعيف في حالة تركيب الثلاجة على أرض غير مستوية.



٢
نظّف الثلاجة.

• امسح ونظّف داخل الثلاجة وخارجها بواسطة قماش خاص لغسيل الطبق بعد تعصيرالماء منه.



٣
ادخل القابس الى مخرج التيار المستقل.

• لا بد من التوصيل الأرضي للثلاجة.
• من الأفضل ان توصل الثلاجة الى مخرج الطاقة الكهربائية بعد تركيبها بساعة واحدة.



٤
ضع الاطعمة في الثلاجة.

• من الأفضل ان تحفظ الأطعمة داخل الثلاجة بعد ادخال القابس الى مخرج التيار بـ ٢ – ٣ ساعات حتى يصبح الهواء في الحجيرة باردا كافيا.

كيفية التوصيل الأرضي

• التوصيل الأرضي يمنع انقطاع الدائرة الكهربائية أو صدمات كهربائية ناشئة عن تسرب الكهرباء من الثلاجة.
• لا بد من عدم التوصيل الأرضي الى أنبوب الغاز ، الخط الهاتفي ، أو مانعة الصواعق مما قد يؤدي الى الأمر الى إحداث الخطر عند برق الصواعق.

في حالة مخرج التيار الكهربائي المستقل مع طرف توصيل أرضي.

• في حالة مخرج التيار الكهربائي مع طرف توصيل أرضي، ليس من الضروري توصيل أرضي اضافي.



في حالة مخرج التيار الكهربائي بدون طرف توصيل أرضي.

• اوصل "سلك التوصيل الأرضي" الى صفيحة نحاسية ، وادفنه في الأرض البال بعمق ٢٥ سم.



التحذيرات

لا تلامس الوعاء والمواد الغذائية داخل حجيرة التجميد باليد المبللة.

• هذا قد يؤدي الى حدي الأذى بالصقيع.

الرجاء ازالة معدن غريب من قابس التيار تماما.

• اذا استخدمت القابس بدون ازالته، قد يحدث احتراق.

اذا أدخلت قابس التيار الى مخرج التيار الجداري بعد سحبه مرة اخرى، ادخله بعد سحبه من مخرج التيار الجداري بخمس دقائق.

• التشغيل غير العادي لجهاز الثلاجة قد يؤدي الى حدث عطل.

انقل الثلاجة بامساك االمقبض الأعلى في الخلف والمقبض الأسفل في الأمام.

• الزلق قد يؤدي الى الإصابة بالجرح في حالة امساك جزء اخر.

استخدم المقبض عند فتح باب الثلاجة وإغلاقه.

• في حالة استخدام اجراء اخرى بدلا من المقبض، قد يؤدي الأمر الى اصابتك بالجرح بسبب ضغط اصبع اليد بالباب.



اذا لم تستخدم جهاز الثلاجة لمدة طويلة، اسحب قابس التيار من مخرج التيار الجداري.

• فساد العزل قد يؤدي الى حدث احتراق.

اذا لم تستخدم جهاز الثلاجة لمدة طويلة، اسحب القابس من الجهاز.

• قد يؤدي فسار العزل الى إحدث احتراق.



عند حدوث صوت أو رائحة أو بخار غير عادي، اسحب قابس التياس من الجهاز فورا، ثم اتصل بمركز الخدمات.



تحذيرات من أجل السلامة

التحذيرات ⚠

لا تحفظ المواد الغذائية الكثيرة داخل الثلاجة.

• فتح الباب قد يؤدي الى تسرب المواد الغذائية الذي قد يتسبّب في العطل.



لا تحفظ الزجاجات أو الاطعمة الضيقة والطويلة في حجيرة صغيرة متعددة الاغراض.

• هذا قد يصيبك بضرر بسبب سقوطها عند فتح باب الثلاجة وإغلاقه .

اذا كانت فتحة مخرج التيار الجداري غير مربوطة باحكام، لا تدخل قابس التيار اليه.

• هذا قد يؤدي الى حدث صدمات كهربائية واحتراق.

لا تضع الزجاجات أو أنواع من الزجاج في حجيرة التجميد.

• تجميد محتويات الزجاج قد يؤدي الى كسر الزجاجات الذي قد يتسبب في اصابتك بالجرح.

لا تضع الاشياء على أعلى جهاز الثلاجة.

• فتح باب الثلاجة أو إغلاقه قد يؤدي الى سقوطها الذي قد يصيبك بالجرح.

لا تسحب سلك التيار بامساك جزء منه فقط.

• الضرر في جزء من السلك قد يؤدي الى إحداث احتراق وصدمات كهربائية.

لا تترك ولدا يعلق بباب الثلاجة.

• قد يصيبه بالجرح في حالة سقوط جهاز الثلاجة أو الضغط على أصبع اليد بالباب.

لا تحفظ الأدوية أو المواد الكيماوية الخ داخل جهاز الثلاجة.

• لا تحفظ المواد التي تكون في حاجة الى ضبط درجة الحرارة.

التنبيهات ⚠

لا تضع وعاء ممتلئا بالماء على أعلى جهاز الثلاجة.

• اذا انصبّ الماء ، فساد عزل الاجزاء الكهربائية قد يؤدي الى حدث احتراق أو صدمات كهربائية.



لا تركب الثلاجة في مكان مبلل أو مكان فيه رش الماء.

• العزل السيء للاجزاء الكهربائية قد يؤدي الى حدث صدمات كهربائية أو احتراق.



لا تدخل قابس التيار الى مخرج التيار الجداري باليد البللة.

• هذا قد يؤدي الى حدث صدمات كهربائية.

لا تجمّع الثلاجة واصلاحها أو تبديل الاجزاء بنفسك.

• هذا قد يؤدي الى حدث احتراق أو تشغيل غير عادي يسبب العطل.



اسحب القابس من مخرج التيار في حالة تبديل المصباح داخل جهاز الثلاجة.

• هذا قد يؤدي الى حدث صدمات كهربائية.



تأكد من التوصيل الأرضي.

• اذا لم تفعل التوصيل الأرضي، قد يحدث قطع الطاقة الكهربائية أو الصدمات الكهربائية. (راجع الصفحة ٦.)



اذا تسرّب الغاز، قم بالتهوية فورا بدون الملامسة بجهاز الثلاجة وقابس الثلاجة.

• التعرض للغاز قد يؤدي الى حدث احتراق واشتعال.



احفظ جهاز الثلاجة بعد فصل الباب أو حشوة الباب في حالة حفظها المطلوب.

• من الخطر لعب الطفل داخل الثلاجة وبابها مغلقة .

تنبيهات من أجل السلامة

هذه تحمي المستخدم أو الاخرين من الإصابة بالضرر أو الجرح ، من خلال تشغيل هذا الجهاز بشكل مناسب. تأكد من الاطاعة لهذه التعليمات من اجل السلامة. (بعد قراءة هذه التعليمات من اجل السلامة، الرجاء الاحتفاظ بها في مكان سحدد للمراجعة)

التنبيه

التنبيه ⚠	يشير الى انه من المتوقع ان يصاب الشخص بالموت أو الجرح الخطير .
التحذير ⚠	يشير الى أنه من المتوقع ان يصاب الشخص بالجرح أو يحدث الضرر في الجهاز .

محتويات المؤشرات

⊘	يشير الى الحظر
	يشير الى حظر التجميع
	يشير الى حظر الملامسة
❗	يشير الى انه يجب عليك ان تخضع لـ ..
	يشير الى أن قابس التيار غير موصول الى مخرج التيار .
⏚	يشير الى ضرورة التوصيل الأرضي لمنع حدث الصدمات الكهربائية.

التنبيهات ⚠

لا تدخل قابسي التيار الكثيرة للاجهزة في نفس الوقت.

• قد تحدث الحرارة غير العادية أو الاحتراق.



اضبط قابس التيار على بعد عن اللوحة الخلفية لجهاز الثلاجة.

• قابس التيار المصاب بالضرر قد يؤدي الى حدث احتراق بسبب الحرارة أكثر مما ينبغي.



لا ترش الماء داخل الثلاجة أو خارجها.

• هذا قد يؤدي الى حدث احتراق أو صدمات كهربائية.



لا ترش الغاز القابل للاشعال قريبا من جهاز الثلاجة.

• هذا قد يؤدي الى حدث انفجار أو احتراق.



لا تلو سلك التيار الكهربائي بالقوة أو لا تضغط على سلك التيار بالشيء الثقيل.

• هذا قد يؤدي الى حدث احتراق أو صدمات كهربائية.



لا تحفظ الاشياء المتطايرة والاشياء القابلة للاشعال في جهاز الثلاجة.

• حفظ البنزين ، ومرقق القوام، والكحول ، والأثير ، غاز البروبين السائل الاخ قد يؤدي الى حدث انفجار .

المميزات

تزويد الهواء البارد المتساوي الى حجيرة التبريد !

- يمكنك حفظ الأطعمة في حالتها الطازجة والمتساوية أكثر من خلال تزويد الهواء البارد المتساوي الى جميع انحاء الثلاجة بواسطة الأجنحة الدوّارة لتوزيع الهواء والتي هي موجودة في مخرج الهواء لحجيرة التبريد. (نظام تدوير الهواء البارد).

تزويد الهواء البارد المتساوي الى حجيرة التجميد !

- يمكنك حفظ الأطعمة في حالتها المتساوية أكثر بواسطة وظيفة دش الهواء للتبريد السريع المتساوي في حجيرة التجميد.

بقاء النضارة بمزيل الروائح الكريهة!

- مزيل بايو الذي يزيل اي نوع من الروائح المنبعثة من الاطعمة في حجيرة التبريد يحتفظ بنكهة الاطعمة الأصلية نضرة.

الفتح والإغلاق السريع السهل بنظام السكة !

- يمكنك ان تخرج الخضراوات والفواكه بسرعة لمنع إضاعة الهواء البارد باتخاذ تصميم نظام سكة حديدية في حجيرة الخضراوات عالية الرطوبة ويمكنك ان تستخدم حجيرة الخضراوات عالية الرطوبة بسهولة بسحب مقبضها ودفعه بلطف فقط.

إغلاق الباب الاتوماتيكي في حالة فتحه القليل.

- في حالة الفتح القليل لباب الثلاجة ، يتم إغلاق الباب اوتوماتيكيا بواسطة وظيفة اغلاق الباب الاوتوماتيكي وتوفير الطاقة الكهربائية.

سوبر أكس فلو

SUPER X-FLOW

نظام تدفق أكس للهواء البارد نظام دوران الهواء الجديد الذي يبرد الهواء داخل حجيرة التبريد بسوعة وتوزع الهواء متساويا بواسطة اجنحة تدوير الهواء البارد في جميع أنحاء الحجيرة.
* بالنسبة لنوع A : راجع صفحة ١١.

تحذير

- قبل تشغيل الجهاز ، الرجاء قراءة هذا الدليل بعناية واحتفظ به للمراجعة في المستقبل.
- تعليمات التشغيل هذه تغطي مختلف الموديلات فمزايا ثلاجتك قد تختلف عما هو مبين في هذا الدليل.
- الجهاز غير مصمم للاستخدام من قبل الأطفال أو العواجز بدون إشراف البالغ عليهم.
- لا بد من الإشراف على الأطفال لضمان أنهم لا يعبثون بالجهاز.
- لا بد من وضع الجهاز بحيث يصل قابس الجهاز الى مخرج التيار بعد التركيب.

المحتويات

المميزات ١
تنبيهات من أجل السلامة ٢
تحذيرات من أجل السلامة ٤
الإجراءات الاستعدادية للتشغيل ٦
كيفية حفظ الأطعمة الصحيح ٧
كيفية التركيب ٨
كيفية استخدام حجيرة التجميد ٩
كيفية استخدام حجيرة التبريد ١١
كيفية فصل المحلقات ١٤
كيفية التنظيف ١٦
إجراءات التركيب ١٨
تحذيرات عند التشغيل ١٩
افحص النقاط أولا قبل طلب الخدمات ٢٠
الجواب عن الأسئلة ٢٢

ARAB

SAMSUNG

تعليمات المالك

جهاز الثلاجة

قبل تشغيل هذا الجهاز، الرجاء قراءة هذه التعليمات
بعناية والاحتفاظ بها للمراجعة في المستقبل.

اذا سحبت قابس التيار من مخرج التيار الجداري، يجب عليك ان تدخله الى مخرج التيار مرة اخرى بعد خمس دقائق.

DA99-00477K REV(0.0)